

# Navigating to a waypoint GPSMAP® 64/64s



Press the **FIND** button and highlight “waypoints” icon and press **ENTER** and **GO**

(Pressing **MENU** lets you sort waypoints by name or distance to you.)

Highlight the waypoint you want to navigate to and press **ENTER**

The map screen is displayed. Highlight **GO** and press **ENTER**.

Bearing and dist to dest is displayed on the map.

Use the **PAGE** button to go to the compass page. It will show your bearing to the waypoint and distance and the compass point will point to the waypoint when moving.

Set your magnetic compass to the bearing and follow it. Read just the compass bearing as you travel until “dist to dest” or “dist to next” is zero.